

Thank you for purchasing our Pro Puck Sharpener. With proper use it will give you years of problem free service with no maintenance.

How to use your **R**azor Sharp Pro Puck Sharpener

1. With one hand, hold your skate upside down with the toe away from you.
2. In your other hand hold "THE PUCK" between your thumb and four fingers.
3. Place the center of the ceramic "V" over the toe end of your skate blade.
4. With very light downward pressure draw "THE PUCK" towards you across the whole length of your blade.
5. Repeat step (4) 1 or 2 more times.

You can also go to www.rspuck.com for more information

Caution: If you apply too much pressure while pulling "The Puck" across your skates they can become too sharp. Take it easy until you get the feel that is right for you.

Thanks again and **Don't Lose your Edge!**